MUD CHAMBER


liquid mud chamber

Mud chamber for installation with an air vent head. Commonly used for ventilating liquid mud tanks on offshore supply vessels.

If mud enters the Mud chamber due to overpressure or overfilling, a one-way flap valve will open and release the mud and the pressure. This is how the mud chamber prevents mud from entering the air vent head. Can be delivered with several types of air vent heads valves.

For pressure drop and flow rate, visit our web page <u>www.gjerde.com</u>





Weight and size

Mud chamber	DN 125/150	DN 150/200	DN 200/250
A (mm)	335	400	510
B (mm)	318	346	430
a (mm)	195	217	280
D	Flange connection acc. to any standard.		
Weight (kg)	32	37	65



Assembly samples for Aero and Hide on Mud Chamber.